

## City of Murray Lockout Tagout Procedures

Gas. 818								
Machine:	Blower 3			1	Plant:	Wastewater Treati	ment Plar	nt
Area:	Filter Press		pdated:	7/9/10		<u> </u>		
Persona	l Protectiv	e Equipment:					_	
5	<b>D</b>					THE CENT		
Safety	Glasses	Steel Toe Shoes	7	g Protection needed)	Lea	ither Gloves (as needed)		
		ROCEDURES:						
ene ser by <sub>l</sub> wh	ergy sources vice on this r bassing a gua ere the unexp	g, and Try to control haza prior to performing mainten nachine, when removing ord, and/or under any circupected start-up or energizated cause bodily harm.						
LOCKOUT PROCEDURE:  (Use this procedure before any servicing or maintenance activities are performed where the expected energization, start up, or release of stored energy may cause injury. (i.e. repairs, set-up, clearing parts, etc.)  Lock Out/Tag Out Equipment Needed:								
		DANGER  We arrange arrange for the control of the c						
Loc			lasp					
<ol> <li>Notify tagout</li> <li>Clear t materia</li> <li>Identify the Filt panel.</li> </ol>	Maintenance: connel that you intend to lont. equipment of tools, parts a dife switch on the southeas ding on the right side of the witch by turning to OFF po	*NOTE	*NOTE* Tag shall include date taken out of service, person/persons that took out of service, and work being					
Energy	Sources:	11						
	Magnitude:	460V						
Energy Iso	lation Device & Location:	Control Panel in Filter Press Building						
After Servicing or Maintenance:								
<ol> <li>Verify all controls are "off" or in neutral position.</li> <li>Clear machine or equipment of tools, parts, or people.</li> <li>Make sure all guarding is in place.</li> <li>Notify affected personnel that the machine or equipment will be reenergized.</li> <li>Remove locks, devices, and tags from energy isolation devices.</li> <li>Re-energize or power-up machine by returning energy isolating</li> </ol>				Ammayada				Date: 7/9/10
devices to normal operating position.					-			