

City of Murray Lockout Tagout Procedures

7									
Machine:				F	Plant:	nt: Wastewater Treatment Plant			
Area:	North Centr		Jpdated:	7/9/10					
Persona	I Protectiv	e Equipment:							
5	D		Sent Comments	Story Constitution of the					
Safety Glasses Steel Toe Shoe		Steel Toe Shoes	Leather Gloves (as needed)		Nit	Nitrile Gloves (as needed)			
		ROCEDURES:							
en se by wh	g, and Try to control haza prior to performing maint nachine, when removing o rd, and/or under any circ pected start-up or energiz could cause bodily harm.		Rotomat Screen 1 cannot be locked out without locking out Rotomat Screen 2 also.						
(Use this pro energy may	cause injury. (i.	DURE: ny servicing or maintenance ac e. repairs, set-up, clearing part Equipment Needed:		erformed where t	he expec	ted energization, start	tup, or rek	ease of stored	
DANGER Image are the second of the second o									
Loc			Hasp						
 Notify tagout Clear tagout Identify panel 	Maintenance: connel that you intend to lont. equipment of tools, parts areen 1 button switch on confirmation. by turning to OFF position	*NOTE	*NOTE* Tag shall include date taken out of service, person/persons that took out of service, and work being						
Energy	Sources:	M							
	Magnitude:	460V							
Energy Is	olation Device & Location:	Control panel in beside Rotomat Screens							
After Ser					1		1		
1. Verify all controls are "off" or in neutral position. 2. Clear machine or equipment of tools, parts, or people. 3. Make sure all guarding is in place. 4. Notify affected personnel that the machine or equipment will be reenergized. 5. Remove locks, devices, and tags from energy isolation devices. 6. Re-energize or power-up machine by returning energy isolating			Ammrayala				Date: 7/9/10	<u> </u>	
	ting position.								